

Mopar Steering Wheel Adapter

Installation Bulletin: #6002

Date: 27 March 06

Subject: Installation of a Flaming River Steering Wheel Adapter to a factory Mopar steering column.

Flaming River Adapter →

Horn Contact →

Cancelling Cam →

Horn Contact
Wire Hole

12 o'clock position

Horn Contact
Wire Hole

Installation Instructions:

- 1) Make sure that your front wheels are centered and straight.
- 2) Turn the wheel adapter over and place the horn contact wire hole at 3 o'clock
- 3) Place the horn contact (from original wheel) wire through the hole ensuring that the tab does not touch the sides of the hole and then set the horn contact onto the wheel adapter.
- 4) Place cancelling cam (from original wheel) onto the wheel adapter aligning the stem with the horn contact wire hole. Set cancelling cam in place by tapping with a hammer until fully seated.
- 5) Flip wheel adapter over and place on to steering column with the alignment dot at the 12 o'clock position as pictured above.
- 6) Tighten down the wheel adapter until there is approximately a 1/16th of an inch gap between the adapter and the column.
- 7) install steering wheel.

FLAMING RIVER

Flaming River Industries
800 Poertner DR
Berea, OH 44017
800-848-8022
www.flamingriver.com