



800 Poertner Dr. Berea, OH 44017  
800-648-8022

## Dodge Steering Column Ignition Switch Wiring Installation

- 1) Measure from the end of your existing connector 6" and cut the wires to remove the connector from the column giving you a pigtail.
- 2) Strip each wire exposing approximately 1/2" of the wire on the factory pigtail and the Flaming River pigtail included with your column.
- 3) Cut qty 4 pieces of shrink tubing (not provided) long enough to sufficiently cover the exposed wire and slide the shrink tubing over the wires of your factory pigtail.
- 4) Solder the appropriate wires together using the diagram below.

### Factory Pigtail

### Flaming River Pigtail

Yellow	connects to	Purple
Black	connects to	Brown
Blue/Brown	connects to	Pink
Red	connects to	Red

- 5) Slide your heat shrink tubing over the wires and heat the tubing to seal the connections.

