



Mopar Wiring Adapter 66-69

Part No. FR20118-7



The Mopar Wiring Adapter (FR20118-7) unites the 4-1/4" female connector from your Flaming River column wiring harness with the stock Mopar connector in your vehicle. This adapter is designed for Mopar vehicles from 1966 to 1969 that commonly use this style connector in turn signal switch wiring harnesses.

Visit **FlamingRiver.com** for Tech Tips

Call Us Toll Free


Telephone: 1-800-648-8022

Fax: 1-800-243-5263


P/N: 102595, Rev A

FR20118-7 Adapter Pin-Out

Top View (FR)



Front View (Mopar)



Function	Flaming River Connector	Mopar Connector
Horn Relay (+12V)	G	4
Left Front Turn Signal	H	1
Right Front Turn Signal	J	3
Hazard Power (+12V)	K	2
Turn Signal Power, Main (+12V)	L	2
Left Rear Turn Signal	M	6
Right Rear Turn Signal	N	8
Brake Light Power (+12V)	P	7
Gearshift Indicator Light	---	5
Unused	---	9, 10



Mopar Wiring Adapter 66-69

Part No. FR20118-7



The Mopar Wiring Adapter (FR20118-7) unites the 4-1/4" female connector from your Flaming River column wiring harness with the stock Mopar connector in your vehicle. This adapter is designed for Mopar vehicles from 1966 to 1969 that commonly use this style connector in turn signal switch wiring harnesses.

Visit **FlamingRiver.com** for Tech Tips

Call Us Toll Free


Telephone: 1-800-648-8022

Fax: 1-800-243-5263


P/N: 102595, Rev A

FR20118-7 Adapter Pin-Out

Top View (FR)



Front View (Mopar)



Function	Flaming River Connector	Mopar Connector
Horn Relay (+12V)	G	4
Left Front Turn Signal	H	1
Right Front Turn Signal	J	3
Hazard Power (+12V)	K	2
Turn Signal Power, Main (+12V)	L	2
Left Rear Turn Signal	M	6
Right Rear Turn Signal	N	8
Brake Light Power (+12V)	P	7
Gearshift Indicator Light	---	5
Unused	---	9, 10